

CMM

Remote Display for Phocos CA, CML and CMLNL



- Measurement and display panel current, load current and battery voltage.
- Clear, readable 3-digit LCD Display
- 3-position switch to select which value to be displayed
- 3LEDs to show which value is displayed by LCD
- Prepared for DIN rail and wall mounting

Phocos' CMM multi-meter is designed to measure and display panel current, load current and battery voltage of your PV system as true values. This provides you more detailed information of your PV system.

CMM can be used in combination with Phocos CA, CML and CMLNL series charge controllers.

TYPE	CMM
Voltage Range	0 to 35V
Current Range	0 to 25A
Operating Temperature Range	-25 to +50 °C
Length of Connecting Wire	2m
Dimension of Measuring Component	84 x44 x32mm
Dimension of Display Component	72 x 68 x29mm
Weight	195gr (with connecting wire)
Case Protection	IP22

Phocos AG, Germany
info@phocos.com

Phocos China Ltd., China
Info-china@phocos.com

Phocos India Solar Pvt. Ltd., India
Info-india@phocos.com

Phocos Latin America S.R.L, Bolivia
Info-latinamerica@phocos.com

Phocos Rep. Office Australia, Australia
Info-australia@phocos.com

Phocos Rep. Office Brazil, Brazil
Info-brazil@phocos.com

Phocos Rep. Office Eastern Africa, Kenya
Info-easternafrica@phocos.com

Phocos Eastern Europe S.R.L., Romania
Info-easterneurope@phocos.com

Phocos SEA Pte Ltd, Singapore
Info-sea@phocos.com

Phocos Rep. Office South Africa
Info-sadc@phocos.com

Phocos Tunisia
Info-maghreb@phocos.com

Phocos USA
Info-usa@phocos.com